

Bench-Top Active Multiplier x4

# X4 Full E Band Active Multiplier, Bench-Top High Power=+25dBm, WR-12



#### **Product Overview**

AT-BTAM4-6090-15 is a E band, active x4 frequency multiplier. The multiplier has an input frequency of 15 to 22.5 GHz with a typical output +25dBm from 60-90GHz.

The integrated input and output buffers deliver high output power at a low drive level. The multiplier also has a typical harmonic suppression of -20dBc. The input port is SMA female, and the output is a WR-12 waveguide with a standard UG-387 flange. Other port configurations are available under different requirement.

More information, please visit www.atmicrowave.com

#### Advantages

Frequency: 60-90GHz

Pout: +25dBm typical

Input: 15-22.5GHz, +3dBm

Bench-Top Labs Test

#### **Application**

- E band Communication
- FOD (Foreigner Objects Debris)
- Test Equipment
- ROF (RF Over Fiber)

### **Key Features**

Parameter	Min	Typical	Max
Input Frequency	15GHz		22.5GHz
Input Power		+10dBm	+13dBm
Multiplier Factor		X4	
Output Frequency	60GHz		90GHz
Output Power	+23dBm	+25dBm	
Harmonica Suppression		-20dBc	
Power Supply	90V	110-220V	240V
Spec Temp		25C	





### Bench-Top Active Multiplier x4

#### **Mechanical Information:**

Parameter	Value
IF Input Port	SMA Female
RF Output Port	WR-12
Power Supply	90v to 240V
	AC to DC Power Converter included
DC Bias Switch	ON-OFF switch with light indicator
Weight	2.5KG
Dimension	See outline

## **Absolute Maximum Ratings Table**

Parameter	Value
Power Supply	+90 to 260V
IF Input Power	+15dBm
Operating Temperature	0 to +50C
Storage Temperature	-65 to +150C

#### **Notes:**

- Datasheet may be changed according to update of MMIC, Raw materials, process, and so on.
- 2. This data is only for reference, not for guaranteed specifications.
- Please contact AT Microwave team to make sure you have the most current data.





Bench-Top Active Multiplier x4

# Test Data (25C)

Please note that test curves will vary slightly from unit to unit.



Pout vs Frequency





Bench-Top Active Multiplier x4

# **Dimension(mm)**

The bottom of the bench-top product is with four support foot pads in default. Mounting bracket option is available according to request.







